Plaza Hocksell (Main) Plaza

10/15/10 Attendant Identification Display AVI (MARKIV) RF Module **ACM Monitor and Mouse** Portable Terminal (PDA) Canopy Override Switch AVI (MARKIV) Antenna Double Vault Cabinet Island Traffic Signals Triple Vault Cabinet Patron Fare Display COMPONENT Lane Controller **Booth Speaker** Receipt Printer LANE LEVEL Touch Screen VES Camera Autosense II Treadle Pad Autosense II Coin Sorter Traffic Loop VES Lights Inspect, clean lens and check cable connections Inspect, check cable connections and alignment Inspect and check cable connections Inspect and check for functionality Inspect and check for connectivity Inspect and adjust diverter cams Inspect and adjust diverter cams Inspect, clean and check cable Inspect and check power cable Inspect and check signal cable Sensor Beam Measurements Inspect, clean and calibrate MAINTENANCE TASK Clean Front Window Inspect and clean Clean Front Lens Inspect / Test Inspect INTERVAL 3 Months 3 Months 1 Week 1 Week 3 Months 3 Months 1 Month 1 Month 1 Week 2 Week 1 Month 2 Week G G G F 3 Ø B 3 F TRMI INITIALS J G 8 8 S 3 3 S 3 S 9 0 8 9 B G 0 8 8 8 8 Ŷ CB G 0 S 0 O J 9 Zewired Replaced Camera Trouble in N3 3 COMMENTS 23

COMPONENT	MAINTENANCE TASK	INTERVAL	TRMI Intials	COMMENTS
PLAZA LEVEL				
AVI (MARKIV) Cabinet	Inspect and clean	3 Months	1	
Leased Modems	Inspect and check cable connections	1 Month	C)	
Wireless Access Point	Inspect and check cable connections	1 Month		
Plaza Workstation	Inspect and check cable connections	6 Months	•	
Laser Printer	Inspect and check cable connections	6 Months		
VES Server	Inspect and check cable connections	6 Months	·	
Ethernet Communications Hub	None			
UPS Units	Check Battery Condition		(S)	
HOSTLEVEL				
Host Computer Database (Toll)	Check database status and performance Receive database export, test backups	1 Week	The state of the s	
	Check database status and performance Receive	•	101	

	6 Months	Inspect, clean	Host Computer Subsystems
Lot	1 Week	Check database status and performance Receive database export, test backups	Host Computer Database (TRToll)
The state of the s	1 Week	Check database status and performance Receive database export, test backups	Host Computer Database (Toll)
			HOST LEVEL

Plaza Hooksell (Side Road)

		3 Months	Inspect, clean lens and check cable connections	Autosense II
		3 Months	Inspect	AVI (MARKIV) RF Module
	<u>(</u>	3 Months	Inspect, clean and check cable	AVI (MARKIV) Antenna
	,	3 Months	Sensor Beam Measurements	Autosense II
	(Y)	1 Month	Clean Front Lens	Island Traffic Signals
	$\bigcirc$	1 Month	Clean Front Window	Patron Fare Display
	(S)	1 Month	Inspect and clean	Lane Controller
		2 Week	Inspect, clean and calibrate	Coin Sorter
		2 Week	Inspect and check for connectivity	Portable Terminal (PDA)
	(7) @ (8) e)	1 Week	inspect and check for functionality	Traffic Loop
	(T) (Q) (Q) (Q)	1 Week	Inspect and check cable connections	Treadle Pad
	(C) (C) (C) (C)	1 Week	Inspect and check cable connections	Attendant Identification Display
		1 Week	Inspect / Test	Canopy Override Switch
		1 Week	Inspect and check cable connections	ACM Monitor and Mouse
		1 Week	Inspect and adjust diverter cams	Double Vault Cabinet
		1 Week	Inspect and adjust diverter cams	Triple Vault Cabinet
		1 Week	Inspect and check power cable	VES Lights
		1 Week	Inspect, check cable connections and alignment	VES Camera
	ත ලා ලා	1 Week	Inspect and check cable connections	Booth Speaker
	(N) (N) (N) (N)	1 Week	Inspect and check cable connections	Touch Screen
	(D) (D) (D)	1 Week	Inspect and check signal cable	Receipt Printer
				LANELEVEL
COMMENTS	TRMI INITIALS	INTERVAL	MAINTENANCE TASK	COMPONENT
•				

COMPONENT	MAINTENANCE TASK	INTERVAL	TRMI Intials	COMMENTS
PLAZA LEVEL				
AVI (MARKIV) Cabinet	inspect and clean	3 Months		
Leased Modems	Inspect and check cable connections	1 Month	\	
Wireless Access Point	inspect and check cable connections	1 Month	(	
Plaza Workstation	Inspect and check cable connections	6 Months	-	
Laser Printer	Inspect and check cable connections	6 Months	Ţ	
VES Server	Inspect and check cable connections	6 Months	(	
Ethernet Communications Hub	None			
UPS Units	Check Battery Condition		T	
HOST LEVEL  Host Computer Database (Toll)	Check database status and performance Receive database export, test backups	1 Week	M	
Host Computer Database (TRToll)	Check database status and performance Receive database export, test backups	1 Week	THE	
Host Computer Subsystems	Inspect, clean	6 Months		

Plaza Bedford Plaza

Attendant Identification Display AVI (MARKIV) RF Module Portable Terminal (PDA) ACM Monitor and Mouse Canopy Override Switch AVI (MARKIV) Antenna Double Vault Cabinet Island Traffic Signals Patron Fare Display Triple Vault Cabinet LANE LEVEL Lane Controller COMPONENT Booth Speaker Receipt Printer Autosense II Autosense II VES Camera Touch Screen Treadle Pad Coin Sorter Traffic Loop VES Lights Inspect, clean lens and check cable connections Inspect, check cable connections and alignment Inspect and check cable connections Inspect and check for connectivity Inspect and check for functionality Inspect and adjust diverter cams Inspect, clean and check cable Inspect and adjust diverter cams Inspect and check power cable Inspect and check signal cable Sensor Beam Measurements Inspect, clean and calibrate MAINTENANCE TASK Clean Front Window Inspect and clean Clean Front Lens Inspect / Test Inspect 3 Months INTERVAL 3 Months 3 Months 3 Months 1 Month 1 Month 1 Month 2 Week 2 Week 1 Week ଟ Ø Ø ଔ ઇ J T J 8 TRMI INITIALS රි ð ð θ G Ø Ø ઇ Ø G 0 0 1 1 G B Ŧ B Ø 0 8 8 Ø O P Q B Ŷ Ø Ø 0 8 Raplace() Tracole in N2 COMMENTS

	THE PARTY OF THE P			
COMPONENT	MAINTENANCE TASK	INTERVAL	TRMI Intials	COMMENTS
PLAZA LEVEL				
AVI (MARKIV) Cabinet	Inspect and clean	3 Months		
Leased Modems	Inspect and check cable connections	1 Month	(C)	
Wireless Access Point	Inspect and check cable connections	1 Month	•	
Plaza Workstation	Inspect and check cable connections	6 Months	J	
Laser Printer	Inspect and check cable connections	6 Months	Ş	
VES Server	Inspect and check cable connections	6 Months	ł	
Ethernet Communications Hub	None			
UPS Units	Check Battery Condition		T	
HOST LEVEL				
-			_	

789
Les

Plaza Exit 10

Attendant Identification Display AVI (MARKIV) RF Module Portable Terminal (PDA) Canopy Override Switch ACM Monitor and Mouse AVI (MARKIV) Antenna Double Vault Cabinet Island Traffic Signals Triple Vault Cabinet Patron Fare Display COMPONENT Receipt Printer LANE LEVEL Lane Controller Booth Speaker Touch Screen VES Camera Autosense II Autosense II Traffic Loop Treadle Pad Coin Sorter VES Lights Inspect, clean lens and check cable connections Inspect, check cable connections and alignment Inspect and check cable connections Inspect and check for functionality Inspect and check for connectivity Inspect and adjust diverter cams Inspect and adjust diverter cams Inspect, clean and check cable Inspect and check power cable Inspect and check signal cable Sensor Beam Measurements Inspect, clean and calibrate MAINTENANCE TASK Clean Front Window Clean Front Lens Inspect and clean Inspect / Test Inspect INTERVAL 3 Months 3 Months 3 Months 3 Months 1 Month 1 Month 1 Month 2 Week 1 Week 2 Week 1 Week 1 Week 4 tt 66 2 3 17.7 tc tc tc tt 17 2 3 25 66 66 66 じい 12 TRMI INITIALS 22 tt 4 12 22 21 3 27  $\mathcal{E}$ 3 CF 27 22 22 10 ピン 7, 22 22 22 23 C 27 77 Ç 2 じじ じい 11 tt. 11 17 22 13 13 COMMENTS

Exit 10

			Check Battery Condition	UPS Units
			None	Ethernet Communications Hub
	27	6 Months	Inspect and check cable connections	VES Server
	77	6 Months	Inspect and check cable connections	Laser Printer
	27	6 Months	Inspect and check cable connections	Plaza Workstation
	27	1 Month	Inspect and check cable connections	Wireless Access Point
	.77	1 Month	inspect and check cable connections	Leased Modems
	7,7	3 Months	Inspect and clean	AVI (MARKIV) Cabinet
				PLAZA LEVEL
COMMENTS	TRMI Intials	INTERVAL	MAINTENANCE TASK	COMPONENT

	6 Months	Inspect, clean	Host Computer Subsystems
THE	1 Week	Check database status and performance Receive database export, test backups	Host Computer Database (TRToll)
B	1 Week	Check database status and performance Receive database export, test backups	Host Computer Database (Toll)
			HOST LEVEL

Plaza Exit 1

Attendant Identification Display AVI (MARKIV) RF Module Portable Terminal (PDA) **ACM Monitor and Mouse** Canopy Override Switch AVI (MARKIV) Antenna Island Traffic Signals Double Vault Cabinet Triple Vault Cabinet Patron Fare Display Lane Controller **Booth Speaker** Receipt Printer LANE LEVEL COMPONENT Touch Screen Autosense II Autosense II VES Camera Treadle Pad Coin Sorter Traffic Loop VES Lights Inspect, clean lens and check cable connections Inspect, check cable connections and alignment Inspect and check cable connections Inspect and check for connectivity Inspect and check for functionality Inspect and adjust diverter cams Inspect and adjust diverter cams Inspect, clean and check cable Inspect and check power cable Inspect and check signal cable Sensor Beam Measurements Inspect, clean and calibrate MAINTENANCE TASK Clean Front Window Inspect and clean Clean Front Lens Inspect / Test Inspect INTERVAL 3 Months 3 Months 3 Months 3 Months 1 Month 1 Month 1 Week 1 Week 1 Week 1 Week 1 Week 1 Month 2 Week 2 Week 1 Week 3 3 33 艺 3 2 Z 3 77 3 Ü Ŀ 7,7 TRMI INITIALS 22 2 2 CE 11/2 62 66 66 CE CE 11 27 70 CF CF EC 22 22 22 3 丝 22 23 111 4 CC CE 2 1.7 1.7. 2 6 7,7 Ü ü 27 12 11 COMMENTS

COMPONENT	MAINTENANCE TASK	INTERVAL	TRMI Intials	COMMENTS
PLAZA LEVEL				
AVI (MARKIV) Cabinet	Inspect and clean	3 Months	7.7	
Leased Modems	Inspect and check cable connections	1 Month	23	
Wireless Access Point	Inspect and check cable connections	1 Month	22	
Plaza Workstation	Inspect and check cable connections	6 Months	<b>)</b> )	
Laser Printer	Inspect and check cable connections	6 Months	<b>)</b> )	
VES Server	Inspect and check cable connections	6 Months	37	
Ethernet Communications Hub	None			
UPS Units	Check Battery Condition			

	6 Months	inspect, dean	Host Computer Subsystems
110	} vveek	natanage export, test naturity	Host Computer Database (TKToil)
The state of the s		Check database status and performance Receive	
M	1 Week	database export, test backups	Host Computer Database (Toll)
121		Check database status and performance Receive	
			HOST LEVEL

FidZd in X 1 1 (d-

	27	2、	3 Months	Inspect, clean lens and check cable connections	Autosense II
	7.7		3 Months	Inspect	AVI (MARKIV) RF Module
	21		3 Months	Inspect, clean and check cable	AVI (MARKIV) Antenna
	77		3 Months	Sensor Beam Measurements	Autosense II
	22		1 Month	Clean Front Lens	Island Traffic Signals
	77	٠, د	1 Month	Clean Front Window	Patron Fare Display
	<i>77</i>	1	1 Month	Inspect and clean	Lane Controller
	1 22	2%	2 Week	Inspect, clean and calibrate	Coin Sorter
	7.1	7.7	2 Week	Inspect and check for connectivity	Portable Terminal (PDA)
	to 60 CC	100	1 Week	Inspect and check for functionality	Traffic Loop
	22 22 22	13	1 Week	Inspect and check cable connections	Treadle Pad
	22 24 22	77 %	1 Week	Inspect and check cable connections	Attendant Identification Display
	te er te	77 7	1 Week	Inspect / Test	Canopy Override Switch
	tt tt tt	1 14	1 Week	Inspect and check cable connections	ACM Monitor and Mouse
			1 Week	Inspect and adjust diverter cams	Double Vault Cabinet
	27 22 22	77	1 Week	Inspect and adjust diverter cams	Triple Vault Cabinet
	22 27 22	77 .	1 Week	inspect and check power cable	VES Lights
	ec ce ce	16	1 Week	Inspect, check cable connections and alignment	VES Camera
	ce ce ce	: cc	1 Week	Inspect and check cable connections	Booth Speaker
	22 22 25	77 ;	1 Week	inspect and check cable connections	Touch Screen
	22 22 21	77;	1 Week	inspect and check signal cable	Receipt Printer
					LANE LEVEL
COMMENTS	TRMI INITIALS	TR.	INTERVAL	MAINTENANCE TASK	COMPONENT

	and the same of th		Check Battery Condition	UPS Units
			None	Ethernet Communications Hub
	33	6 Months	Inspect and check cable connections	VES Server
	22	6 Months	Inspect and check cable connections	Laser Printer
	22	6 Months	Inspect and check cable connections	Plaza Workstation
	77	1 Month	Inspect and check cable connections	Wireless Access Point
	22	1 Month	Inspect and check cable connections	Leased Modems
	22	3 Months	Inspect and clean	AVI (MARKIV) Cabinet
				PLAZA LEVEL
COMMENTS	TRMI Intials	INTERVAL	MAINTENANCE TASK	COMPONENT

Check database status and performance Receive database export, test backups  Check database status and performance Receive database export, test backups  Inspect, clean  6 Months
Week Week Week

Plaza Hampton Side Road

Attendant Identification Display AVI (MARKIV) RF Module ACM Monitor and Mouse Portable Terminal (PDA) Canopy Override Switch AVI (MARKIV) Antenna Double Vault Cabinet Island Traffic Signals Triple Vault Cabinet Patron Fare Display LANE LEVEL COMPONENT Booth Speaker Receipt Printer Lane Controller Touch Screen VES Camera Autosense II Autosense II Traffic Loop Treadle Pad Coin Sorter VES Lights Inspect, clean lens and check cable connections Inspect, check cable connections and alignment Inspect and check cable connections Inspect and check for connectivity Inspect and check for functionality Inspect and adjust diverter cams Inspect and adjust diverter cams Inspect, clean and check cable Inspect and check power cable Inspect and check signal cable Sensor Beam Measurements Inspect, clean and calibrate MAINTENANCE TASK Clean Front Window Clean Front Lens Inspect and clean Inspect / Test Inspect INTERVAL 3 Months 3 Months 3 Months 3 Months 1 Month 1 Month 1 Week 1 Month N/A N/A NA N N Z 3 S Z N.A  $\leq$ Ş نم Ş NA N/A N N. TRMI INITIALS Š Sy 1002 ξ.  $\rho \omega$ 5/2 Ę <u>ي</u> ک ΝÄ NA Z C NA N/A NA ₹ 2 کی وز SNW SOL Ê £ 30 St 13 SAJ N/A N. N/A N N 5 Z. <u>ځ</u>ر N/A N/A N/A ķ Ŝ JηJ N/A 763 NA <del>\</del> Ę, Ě COMMENTS

COMPONENT	MAINTENANCE TASK	INTERVAL	TRMI Intials	COMMENTS
PLAZA LEVEL				
AVI (MARKIV) Cabinet	Inspect and clean	3 Months	. ) <i>PU</i>	
Leased Modems	Inspect and check cable connections	1 Month	S/W	
Wireless Access Point	Inspect and check cable connections	N/A	N/A	
Plaza Workstation	Inspect and check cable connections	6 Months	500	
Laser Printer	Inspect and check cable connections	6 Months	503	
VES Server	Inspect and check cable connections	6 Months	\9.J	
Ethernet Communications Hub	None			
UPS Units	Check Battery Condition		بدمك	

Host Computer Subsystems	Host Computer Database (TRToll)	Host Computer Database (Toll)	HOST LEVEL
inspect, clean	Check database status and performance Receive database export, test backups	Check database status and performance Receive database export, test backups	
6 Months	1 Week	1 Week	
	2	2 de	

Plaza Hampton Main Month August 2010

			,	2 Months	Inspect, clean lens and check cable connections	Autosense II
		J	λοί	3 Months	Inspect	AVI (MARKIV) RF Module
		C.	٦٩٧	3 Months	Inspect, clean and check cable	AVI (MARKIV) Antenna
		ر	ں د ز	3 Months	Sensor Beam Measurements	Autosense II
			نمز	1 Month	Clean Front Lens	Island Traffic Signals
			ن مر	1 Month	Clean Front Window	Patron Fare Display
		C	Şρυ	1 Month	Inspect and clean	Lane Controller
A	N/A N/A	N A	N/A	N/A	Inspect, clean and calibrate	Coin Sorter
A	N/A N/A	N/A	N/A Z	N/A	Inspect and check for connectivity	Portable Terminal (PDA)
	(SO) (SO)	Συ-7 Σ	<u>ځ</u> ح	1 Week	Inspect and check for functionality	Traffic Loop
0	i i	SHU SHU	Уи Уи	1 Week	Inspect and check cable connections	Treadle Pad
	SOU DAN	310 8	ين له مح	1 Week	Inspect and check cable connections	Attendant Identification Display
A	N/A N/A	N/A N	N/A N	N/A	Inspect / Test	Canopy Override Switch
A	N/A N/A	N/A N	N/A	N/A	Inspect and check cable connections	ACM Monitor and Mouse
A	N/A N/A	N/A Z	N/A N	N/A	Inspect and adjust diverter cams	Double Vault Cabinet
À	N/A N/A	N/A N	N/A N	N/A	Inspect and adjust diverter cams	Triple Vault Cabinet
	Sylu	d Ju	50-1 50-1	1 Week	Inspect and check power cable	VES Lights
	روز ل	ر ان الإر	سوک سهر	1 Week	Inspect, check cable connections and alignment	VES Camera
Replaced S6 speaker	W Sau	u Sm	mK. P	1 Week	Inspect and check cable connections	Booth Speaker
	کو مطر	ļ	يمور المؤ	1 Week 5	Inspect and check cable connections	Touch Screen
	Stalson	<u>ک</u> ک	عد لدور	1 Week	Inspect and check signal cable	Receipt Printer
				-		LANE LEVEL
COMMENTS	ALS	TRMI INITIALS	TRN	INTERVAL	MAINTENANCE TASK	COMPONENT

Month August 2010

	The	1 Week	Check database status and performance Receive database export, test backups	Host Computer Database (TRToll)
	The state of the s	1 Week	Check database status and performance Receive database export, test backups	Host Computer Database (Toll)
				HOST LEVEL
	(D)		Check Battery Condition	UPS Units
			None	Ethernet Communications Hub
	SpJ	6 Months	Inspect and check cable connections	VES Server
	)// <i>U</i>	6 Months	Inspect and check cable connections	Laser Printer
	SpJ	6 Months	Inspect and check cable connections	Plaza Workstation
	N/A	N/A	Inspect and check cable connections	Wireless Access Point
	SpJ	1 Month	Inspect and check cable connections	Leased Modems
	Sou	3 Months	Inspect and clean	AVI (MARKIV) Cabinet
				PLAZA LEVEL
COMMENTS	TRMI Intials	INTERVAL	MAINTENANCE TASK	COMPONENT

Host Computer Subsystems

Inspect, clean

Plaza Dover Toll Plaza

Attendant Identification Display AVI (MARKIV) RF Module ACM Monitor and Mouse Portable Terminal (PDA) Canopy Override Switch Double Vault Cabinet AVI (MARKIV) Antenna Triple Vault Cabinet Island Traffic Signals Patron Fare Display LANE LEVEL Receipt Printer COMPONENT **Booth Speaker** Lane Controller Touch Screen VES Camera Autosense II Autosense II Treadle Pad Coin Sorter Traffic Loop VES Lights Inspect, check cable connections and alignment Inspect, clean lens and check cable connections Inspect and check for functionality Inspect and check for connectivity Inspect and adjust diverter cams Inspect and adjust diverter cams Inspect and check power cable Inspect and check signal cable Inspect, clean and check cable Sensor Beam Measurements Inspect, clean and calibrate MAINTENANCE TASK Clean Front Window Inspect and clean Clean Front Lens Inspect / Test Inspect INTERVAL 1 Week 1 Week 3 Months 3 Months 3 Months 3 Months 1 Week 1 Week 1 Week 1 Week 1 Month 1 Mo⊓th 1 Month 2 Week 1 Week 1 Week 1 Week 1 Week 1 Week N. N N D R 2 M. N/A RC RC RC N PO RO RO PO 0 7 RU  $\bigcap_{i \in \mathcal{I}_i} \mathcal{I}_i$ TRMI INITIALS No Mo Replaced N1 Speaker RC PC RC DE 20 20 Z N/A 0 BC RC RC M. D. M. PORC 200 B N. NA N/A N/A Replaced S4 Treadle COMMENTS

COMPONENT	MAINTENANCE TASK	INTERVAL	TRMI Intials	COMMENTS
PLAZA LEVEL				
AVI (MARKIV) Cabinet	Inspect and clean	3 Months	2 C	
Leased Modems	Inspect and check cable connections	1 Month	РC	
Wireless Access Point	inspect and check cable connections	N/A	ţ	
Plaza Workstation	Inspect and check cable connections	6 Months	RO	
Laser Printer	Inspect and check cable connections	6 Months	RC	
VES Server	Inspect and check cable connections	6 Months	Ra,	
Ethernet Communications Hub	None			
UPS Units	Check Battery Condition		<i>*</i>	

	6 Months	inspect, clean	Host Computer Subsystems
The	1 Week	Check database status and performance Receive database export, test backups	Host Computer Database (TRToll)
M	1 Week	Check database status and performance Receive database export, test backups	Host Computer Database (Toll)
			HOST LEVEL

Rochester Toll Plaza Month August 2010

	RC.	3 Months	Inspect, clean lens and check cable connections	Autosense II
	ŘŎ	3 Months	Inspect	AVI (MARKIV) RF Module
	RC.	3 Months	inspect, clean and check cable	AVI (MARKIV) Antenna
	$\check{\mathcal{L}}^{\mathcal{H}}$	3 Months	Sensor Beam Measurements	Autosense II
	A.	1 Month	Clean Front Lens	Island Traffic Signals
	6.6	1 Month	Clean Front Window	Patron Fare Display
	RS	1 Month	Inspect and clean	Lane Controller
	KC BC	2 Week	Inspect, clean and calibrate	Coin Sorter
	N/A N/A	N/A	Inspect and check for connectivity	Portable Terminal (PDA)
	ec loc loc loc	1 Week	Inspect and check for functionality	Traffic Loop
	REREKE	1 Week	Inspect and check cable connections	Treadle Pad
	RCRCRC RC	1 Week	Inspect and check cable connections	Attendant Identification Display
	rc bc bc/rc	1 Week	Inspect / Test	Canopy Override Switch
	ac pc ac ac	1 Week	Inspect and check cable connections	ACM Monitor and Mouse
	RORC DE DE	1 Week	inspect and adjust diverter cams	Double Vault Cabinet
	N/A N/A N/A N/A	A/N	Inspect and adjust diverter cams	Triple Vault Cabinet
	RC RC RC RC	1 Week	Inspect and check power cable	VES Lights
	RO RO RO MO	1 Week	Inspect, check cable connections and alignment	VES Camera
	RC RO RO RC	1 Week	Inspect and check cable connections	Booth Speaker
	CALA	1 Week	Inspect and check cable connections	Touch Screen
Replaced S1_frayed priner cable	PORT ROBO	1 Week	Inspect and check signal cable	Receipt Printer
				LANELEVEL
COMMENTS	TRMI INITIALS	INTERVAL	MAINTENANCE TASK	COMPONENT

Je Je	1 Week	Check database status and performance Receive	HOSI LEVEL
			TOOT I EVE
CC.		Check Battery Condition	UPS Units
		None	Ethernet Communications Hub
P.C.	6 Months	Inspect and check cable connections	VES Server
CC.	6 Months	Inspect and check cable connections	Laser Printer
RC	6 Months	Inspect and check cable connections	Plaza Workstation
N/A	N/A	Inspect and check cable connections	Wireless Access Point
RC.	1 Month	Inspect and check cable connections	Leased Modems
2 C,	3 Months	Inspect and clean	AVI (MARKIV) Cabinet
			PLAZA LEVEL
TRMI Intials	INTERVAL	MAINTENANCE TASK	COMPONENT

Host Computer Subsystems	Check database status and performance Receive Host Computer Database (TRToll) database export, test backups	Check database status and performance Receive Host Computer Database (Toll)  database export, test backups	HOST LEVEL
t, clean 6 Months	nd performance Receive 1 Week	nd performance Receive t, test backups 1 Week	
	Her	The state of the s	